


Instructions for Kindle Fire (5th Generation)

The on button is located at the top right of the Kindle Fire. (See A) On the top of the device, the volume, head phone jack, microphone, and micro SD for charging are also available. (See A)

Hold down the on button for a few seconds to turn on the device. Swipe the lock from middle then up to open the home screen. (See B)

On your home screen you will see all the apps that are available. Ignore this screen and select books. (See C)



Tap the cover of the book you would like to read. After the book has opened, tap the sides of the screen to move forward and backward: left side to go back a page and right side to go forward a page.

Tap the middle of the screen to get your menu buttons and to return to the home screen.

Aa : menus to adjust text, screen color, screen position and line spacing.

▶ : Will read the text on the page for you. The + and – on the back of the Kindle will increase and decrease the volume

Other accessibility features are hidden in the menu at the top of the screen. Swipe the screen from top to bottom, you will find the settings cog here. After clicking settings you will find accessibility in the next menu.

Several other features such as: a screen magnifier and large font sizes are hidden here.

○ : This button will take you to the main home screen.

Powering off: hold down the on button till the message “Do you want to shut down your Kindle?” appears. Click the “power off” button to shut down the Kindle.

To charge the Kindle: Plug the cord into the device and then put the plug into the wall. You will get 10 hours of battery life with the Kindle before you need to charge it.